


# Threading Diagram – Gammill® Classic & Optimum (Plus Models)



9. Thread over the first "L" shaped post, down, then clockwise around the rotary tension (1 & 3/4 times), over the check spring and under the second post.